

## HTRF<sup>®</sup> Terbium cryptate donor / Green acceptor readout Setup recommendations for SpectraMax<sup>®</sup> M5<sup>e</sup>

Two sequential measurements should be carried out: at 620 nm for the cryptate emission, and at 520 nm for the specific signal emitted by the acceptor. The ratio\* of the two fluorescence intensities 520/620 (acceptor/donor) enables the calculation of Delta F (%) which represents the relative energy transfer rate for each sample.

SpectraMax<sup>®</sup> M5e readers must be appropriately configured for HTRF<sup>®</sup> readout by setting up the measurement conditions in the SoftMax Pro software. In particular, these parameters should be entered as defined in the table below. No special upgrade is required for HTRF<sup>®</sup> readout, as it is a monochromator-based instrument.

Read mode	
	Time-Resolved Fluorescence (RFUs)
Integration delay	50 µs
Integration	300 µs
	Top read
Wavelenghts	
Excitation 1	340 nm
Emission 1	520 nm
Cut off for emission 1	495 nm
Excitation 2	340 nm
Emission 2	620 nm
Cut off for emission 2	570 nm
Sensitivity	
Readings	50 to 100
PMT	Optimal
Column Wavelenght	
	Column Priority

This reader only allows high performance HTRF measurement when assays are run in WHITE plates.

